



**PITCH DAM NOTE:**  
 Install a 3'x3' sheet of organic base or two plies of 15lb felt, centered over the drain bowl and set in steep asphalt or asphalt mastic. After the coal tar membrane plies are in place, cut through the membrane and pitch dam felt approximately 2 inches back from around the drain bowl flange and remove the felt covering the drain bowl. Cover the drain bowl flange, the exposed insulation and 4 inches onto the membrane with two plies of fabric set into alternate coats of asphalt mastic.

30" X 30" (2 1/2 - 4 LB) lead sheet set in a full bed of asphalt mastic. Prime top surface of lead with appropriate primer and allow to dry prior to installing stripping. Stripping should consist of two plies. The top target ply should extend under clamping ring along with the lead to the inside edge of the drain bowl.

**DURAPAX**<sup>TM</sup>  
**COAL TAR**  
**COMMERCIAL ROOFING SYSTEMS**

**ROOF DRAIN WITH TAPER**

DATE: 1-1-06	SCALE: NONE	DRAWING NO.: B03ISO
-----------------	----------------	------------------------